

Use this template only if these holes are not already pre-drilled. Otherwise, loosen any screws already installed to slip the rack in place.

Fashion Sewing Cabinets of America

Model 8300 - Pfaff Module Rack Drill Template

Print on 8.5"x14" Legal size paper. When printing from a PDF change the printer properties to match Legal size paper to prevent default scaling to 8.5"x11".

Mark and drill eight $\frac{3}{32}$ " holes $\frac{1}{2}$ " deep as shown. Use the $\frac{5}{8}$ " Phillips screws to attach the U-Straps around the module rod to the cabinet.

