

Sewing Power at Your Fingertips

Décor Computer DC3050

AUTO-LOCK AND UP/DOWN NEEDLE POSITION BUTTONS



AUTO-DECLUTCH BOBBIN WINDER

Simply insert thread into the bobbin, place the bobbin on the bobbin winder spindle and press the foot controller. The machine will finish the bobbin winding process automatically, creating perfect bobbins every time.



STITCH NUMBER, WIDTH AND LENGTH BUTTONS


Select or adjust stitches for your personal sewing needs.

The bright and easy-to-read LED shows selection numerically.

DIRECT STITCH SELECTION BUTTONS

Speedy, one-touch selection for stitches used most frequently.

STITCH PACKAGE





REVERSE STITCH BUTTON

SPEED CONTROL SLIDER

AUTO-LOCK AND UP/DOWN NEEDLE POSITION BUTTONS

Secure the end of a seam with the Auto-lock button. Press the up/down needle position button to conveniently set the needle in the up or down position. The machine will automatically stop at the end of the seam in the position started.



BUILT-IN NEEDLE THREADER

Easy needle threading and less strain on your eyes.



SFS (Superior Feed System)

7 piece feed dog supports fabric on all sides of needle --- front, back, left, right. Provides smooth, consistent, pucker-free results on a wide variety of fabric.



FULLY AUTOMATIC SENSOR BUTTONHOLE

Simply place a button on the sensor buttonhole foot. The sensor then sets the necessary length, and the perfect buttonhole is automatically made in one step. There are three styles of buttonholes, square, round-end and keyhole buttonholes to choose from.



CONVERTIBLE FREE ARM FOR CIRCULAR SEWING

The detachable sewing table easily slides out of the way to reveal the free arm — so handy for sleeves, cuffs and hard-to-reach areas.



Janome America Inc.

10 Industrial Avenue Mahwah, NJ 07430 800-631-0183 www.janome.com