

# The main features at a glance

	9910	9920	9940
Total number of stitch programs	169	348	525
Alphabet styles with upper and lower case, numerals, punctuation marks	1	2	3
Professional buttonhole styles	4	8	12
Exclusive SINGER® underplate one-step buttonhole system	•	•	•
LCD display showing stitch details	•	•	•
Memory for pattern storage (maximum storage capacity)	20	40	60
Stitch width up to 7 mm	•	•	•
Top drop-in bobbin for fast and easy bobbin changing	•	•	•
Quick threading system	•	•	•
Automatic needle threader	•	•	•
Convenient thread cutter on face plate	•	•	•
Snap-on presser feet	•	•	•
Presser foot pressure adjustment – 3 settings for sewing of multiple fabric layers	•	•	•
Optimum Power Control for full needle-piercing power at every speed	•	•	•
Drop feed control for darning or free motion work	•	•	•
24 needle position variations – Ideal for quilting or topstitching	•	•	•
Needle up/Needle down	•	•	•
Twin needle function – Halves the width of stitch patterns	•	•	•
One-touch reverse sewing function	•	•	•
Mirror image of utility and decorative patterns	•	•	•
Sewing speed up to 900 stitches per minute	•	•	•
Easy free arm/flat bed conversion	•	•	•
Ergonomic work surface for easy handling of bulky sewing projects	•	•	•
Horizontal spool pin	•	•	•
Built-in accessory storage	•	•	•
Built-in carrying handle	•	•	•
Reverse image of utility and decorative patterns	•	•	•
Pattern editing function	•	•	•
Single pattern/continuous pattern option	•	•	•
Stitch elongation of satin stitches (up to 5x)	•	•	•
Center position straight stitch auto back-tack function	•	•	•
Stitch elongation of selected utility and decorative patterns (2x)			•
Pictogram operation – No text reading			•
Audible and visual warning messages			•
Basting function for quick piecing			•
Slow sewing button – Cuts speed range in half for delicate sewing work			•