

ALL ABOUT the edge joining foot

The edge joining foot is one of the most popular and widely-used feet available for your sewing machine. This foot makes everything from edgestitching to stitch-in-the-ditch to heirloom sewing easier.

The center bar (1) is the perfect guide for fabric edges. Unlike the blindhem foot where the bar extends into the needle hole, the edge joining foot's bar stops before the hole making it possible to use any stitch on your machine with this foot.

The marks on each side make aligning your fabrics or turning easier. The second mark (2) on the left side lines up with the slight indentation (3) on the right side of the foot. Use these marks to start sewing two lace edges or fabric and lace in the same place.

To begin sewing, place the edge of the fabric, lace or trim against the left edge of the bar on the foot. Choose a straight or zigzag stitch that will catch the edge of the fabric or trim as well as sew into the background fabric.

