

**PGM Ladies Half Body Dress Form Installation Guide**

Please check the following items in your package

1 qty Caster Base with Pedal



1 qty Spring



1 qty Inner pole



1 qty Outer pole



1 qty DRESS FORM



1 qty Topper



**Step 1**

Place **BASE** firmly on the ground.



**Step 2**

Insert **SPRING** through bottom end of **INNER POLE**



**Step 3**

Insert **INNER POLE** into the **BASE** all the way to the bottom until foot pedal flip up.



**Step 4**


Use a screw-driver or any similar tool to tighten by inserting into hole and turning clockwise to tighten the **INNER POLE** into the **BASE**.

**Tips: Please make sure it is REALLY TIGHT! This is the most important part of the installation.**



**Step 5**

Slide OUTER POLE (Item 4) through INNER POLE (Item 3) while stepping on the pedal. Stepping on the pedal makes the “cut” at the top of INNER POLE align.



**Tips: It does not have to be 100% align, as long as the OUTER POLE can fit and slide through INNER**

**STEP 6**

Put the DRESS FORM over OUTER POLE and secure Dress Form with the topper!



**Congratulation! Installation Complete!**

**Tips**

- You can easily adjust the height or rotate the dress form by:
  1. Stepping on the pedal
  2. Lifting the dress form / Rotate the dress form
  3. Let go of pedal

**(If you do not follow these tips, you might damage the interior structure of the dress form.)**