



# SPORT QUICK START GUIDE


## ASSEMBLY




**Simplicity**  
*SPORT*




Scan code for Owner's Manual  
and product support.




Insert hose



Connect hose to wand



Attach floor tool



Attach strap

**Simplicity**  
VACUUMS

# SPORT QUICK START GUIDE

## OPERATION

### WARNING

Electric shock could occur if used outdoors or on wet surfaces. See owner's manual for important safety instructions.

