



GO!® Oven Mitt


Item Number: 55563



Use cotton fabric and a heat resistant batting such as Insul-Bright® to protect your hands from burns. For best results, sandwich the insulated batting between outer layer and lining and quilt the sandwich prior to cutting. Cut only one quilted sandwich at a time. If you are using contrasting fabric for the lining, be sure to cut one section with the outer fabric facing up and one with it facing down. Use the GO! Strip Cutter-2½" (2" Finished) (55017 or 55014) for binding.

How to Sew the Oven Mitt:

Step 1




Lay one 10" x 16" piece of lining fabric right side down on table in front of you. Top with one 10" x 16" piece of insulated batting.

Lay one 10" x 16" piece of outer fabric on top of batting, pin or baste together. Repeat with remaining lining, batting and outer layers.

Quilt as desired.


Step 2



Lay one "sandwich" on die with outer fabric facing up, cover with mat and cut.

Repeat with second piece but be sure to place it with the outer fabric facing the foam and cut.

Step 3



Place outer fabrics together, keeping the lining fabric sides facing out and pin. Sew a ¼" seam allowance around the mitt, leaving the bottom edge open.

Backstitch when starting and stopping. Turn mitt right side out.

Create binding and loop using the GO! Strip Cutter-2½" (2" Finished) (55017 or 55014).