

User

2)



001



002



003



004



005



006



007



008

20



63



4854



82.7mm



89.5mm



7



72



0



1)



USB



USB



1) Touch the Design or User icon.

2) Choose the design you want.

User



001



002



003



004



005



006



007



008



1

/

20



63

Apply the design

99 %



Select Design



Design



User



1



2



S.E.S



Close

Touch the Save icon.

Setting

Mirror

X



X Scale(%)

100



Y Scale(%)

100



Angle

0



Jump stitch to create trim

3



Inching stitch after trim

5



Start point return

YES

NO

Upper thread sensing count

5



Inching stitch

5



RPM

700




Close

Set the inversion angle by touching in Mirror.
Touch the Close X icon to complete the setup.

700

2024.02.02 | 15:01



Touch the Setting icon.

Setting

Mirror

X



X Scale(%)

100



Y Scale(%)

100



Angle

0



Jump stitch to create trim

3



700

2024.02.02 | 15:02

IDLE

- 1
- 2
- 3
- 4

63



C

89.5 mm

Mirror X : The design will be mirrored left and right.

Setting

Mirror

Y



X Scale(%)

100



Y Scale(%)

100



Angle

0



Jump stitch to create trim

3



700

2024.02.02 | 15:02

- 1
- 2
- 3
- 4

IDLE



Mirror Y : The design will be mirrored up and down.

Setting

Mirror

X+Y



X Scale(%)

100



Y Scale(%)

100



Angle

0



Invertable to create trim

2024.02.02 | 15:02

- 1
- 2
- 3
- 4

IDLE



Mirror X+Y : The design is mirrored both vertically and horizontally.

Setting

Mirror

No



X Scale(%)

100



Y Scale(%)

100




1)

Angle


2)

30



i IDLE

63



C : 7



±
95.1 mm



4,854 ST.

90.7 mm



30 °

3)

Set the 2) Angle size in 1) Angle.

Check the angle size with 3).